


29. PART LIST

PARTS LIST INTERSTATER MK6 SUBFRAME ASSEMBLY

No	Part Number	Description	Qty
1	01-S-2301	INTERSTATER MK6 SUBFRAME	1
2	15-1514	BODY MOUNT PLATE	6
3	BURUB-0005	BODY MOUNT RUBBER	18
4	01-S-2303	MAIN BOOM PIVOT BLOCK ASSY	2
5	M0713129	RAM TOP LEG PIN	1
6	M0805999	CENTURY LEGS	1
7	M0805965	INNER LEG LHS	1
8	M0713128	RAM BOTTOM LEG PIN	2
9	M0715694	SPADE PIVOT PIN	2
10	M0804334	MULTI POSITION PIN	2
11	M0705485	FOOT TOOTH PLATE	2
12	M0804286	LOWER SPADE FOOT	2
13	M0303691	LEG RAM	2
14	M0805966	INNER LEG RHS	1
15	M0708452	D LOOP	2
16	MGA0215	D LOOP PIN	2


**PARTS LIST
 INTERSTATE MK6
 SUBFRAME ASSEMBLY**



PARTS LIST INTERSTATER MK6 H BOOM ASSEMBLY

No	Part Number	Description	Qty
1	04-S-4075	H BOOM OUTER BOOM	1
2	04-S-4002	H BOOM INTERMEDIATE BOOM	1
3	04-S-4039	H BOOM INNER BOOM	1
4	04-S-4032	END CAP FABRICATION	1
5	08-1316	EXTEND CYLINDER	1
6	04-4038	RAM PIN OUTER BOOM	1
7	FTSPI-5035	SOCKET CAP HD BOLT M16 x 35 (GRADE 10.9)	2
8	04-4037	BASE SHEAR PLUG	2
9	HYVAL-0021	DOUBLE PILOT CHECK VALVE	1
10	02-2368	FOLD RAM PIN LOWER	1
11	02-2364	MAIN FOLD PIN	1
12	M0302538	BEARING	3
13	FTSCF-5030	SOCKET COUNTERSUNK M10 x 30 BZP	20
14	04-1386	REMOVABLE STOP	4
15	04-1421	REMOVABLE STOP	2
16	04-4043	END BLOCK RAM PIN	1
17	04-4044	PIN RETAINING CAP	2
18	06-112	ANTISWIVEL PIN	1
19	FBSPH-5080	SOCKET CAP HD BOLT M14 x 80 (GRADE 12.9)	2
20	06-123	PIVOT PIN TOP	1
21	13-830	HEAVY DUTY EUROGRID BUSH	1
22	06-S-093	BONIFACE LIFT BAR	1
23	06-124	PIVOT PIN BOTTOM	1

**PARTS LIST
 INTERSTATER MK6
 H BOOM ASSEMBLY**




PARTS LIST

INTERSTATER MK6

I BOOM ASSEMBLY

No	Part Number	Description	Qty
1	04-S-4126	I BOOM OUTER BOOM	1
2	04-S-4102	I BOOM INTERMEDIATE BOOM	1
3	04-S-4115	I BOOM INNER BOOM	1
4	04-S-4032	END CAP FABRICATION	1
5	08-1318	EXTEND CYLINDER	1
6	04-4038	RAM PIN OUTER BOOM	1
7	FTSPI-5035	SOCKET CAP HD BOLT M16 x 35 (GRADE 10.9)	2
8	04-4037	BASE SHEAR PLUG	2
9	HYVAL-0021	DOUBLE PILOT CHECK VALVE	1
10	02-2368	FOLD RAM PIN LOWER	1
11	02-2364	MAIN FOLD PIN	1
12	M0302538	BEARING	3
13	FTSCF-5030	SOCKET COUNTERSUNK M10 x 30 BZP	20
14	04-1386	REMOVABLE STOP	4
15	04-1421	REMOVABLE STOP	2
16	04-4043	END BLOCK RAM PIN	1
17	04-4044	PIN RETAINING CAP	2
18	06-112	ANTISWIVEL PIN	1
19	FBSPH-5080	SOCKET CAP HD BOLT M14 x 80 (GRADE 12.9)	2
20	06-123	PIVOT PIN TOP	1
21	13-830	HEAVY DUTY EUROGRID BUSH	1
22	06-S-093	BONIFACE LIFT BAR	1
23	06-124	PIVOT PIN BOTTOM	1

PARTS LIST
INTERSTATER MK6
I BOOM ASSEMBLY



PARTS LIST **INTERSTATER MK6** **MAIN ASSEMBLY**

No	Part Number	Description	Qty
1	02-2323	MAIN PIVOT PIN	1
2	02-2321	MAIN PIVOT BEARING	2
3	GNSTR-0004	GREASE NIPPLE M6 STRAIGHT	2
4	02-S-2300	MAIN BOOM	1
5	02-S-2326	SWING RAM PIN, DOWN BOOM	1
6	FBHBG-5030	HEX BOLT M12 x 30mm	2
7	02-S-2333	LIFT RAM PIN LOWER PIN	2
8	FBHBK-5060	HEX BOLT M12 x 60mm	2
9	02-1331	RETAINING WASHER	2
10	02-2303	MAIN/DOWN BOOM PIVOT PIN	1
11	02-1349	SHIM – MAIN BOOM	2
12	FBHBG-5030	HEX BOLT M12 x 30mm	2
13	08-2303	LIFT RAM	2
14	M0906535	FAIRLEAD/SHEAVE ASSEMBLY	2
15	02-S-2345	DOWN BOOM	1
16	08-2302	SWING RAM	2
17	02-S-2331	SWING RAM PIN, MAIN BOOM	1
18	HYVAL-0021	DOUBLE PILOT CHECK VALVE	1
19	02-S-2338	FOLD RAM TOP PIN	1
20	02-S-2364	UNDERLIFT MAIN PIVOT PIN	1
21	M9048800	HOOK BACK LINK	2
22	M945030007	HOOK BACK SPRING	2
23	M0400257	HEX BOLT M12 x 80mm	2
24	HYCYL-0006	FOLD RAM	2
25	02-S-2368	FOLD RAM LOWER PIN	1
26		H/I BOOM (SEE OVER)	1
27		BONIFACE LIFTBAR	1

